



## Operation of the DPF1C "one reference"



- Λ = Parallel up
- ∨ = Parallel down
- S = Store memory
- = Memory 1
- = Memory 2
- = Memory 3



### Up and down (Λ∨):

Just activate either the up or down button for parallel drive and the system will drive until the button is released again or the system reaches end position.

### Memory:

The four small buttons are used for memory drive/storing memory.

### Store memory

- Press S – button, the display will flash for 2 seconds
- Within these two seconds press one of the small buttons with dots and the position will be stored at this button.
- The panel will acknowledge by showing "1", "2" or "3" in the display depending on chosen position

### Memory drive (small buttons with dots)

Press one of the memory buttons and the system will start driving to the pre-programmed memory position. Keep the button pressed until the position is reached.

### Display function

Shows the actual height in either cm or inch.